apollo

Conventional Manual Call Point Installation Guide

Part No	Product Name	Type
SC2900-001	Conventional Manual Call Point	Indoor

Technical Information

IP IP44   **°C** -40°C to 70°C   **V** 18-30 V dc

Product Overview

	Item	Qty		Item	Qty
1.	Head unit	1	5.	Fixing screws (NOT SUPPLIED)	N/A
2.	Fixing screws	2			
3.	Mounting bracket	1	6.	Backbox	1
4.	Earth Continuity Terminal	1	7.	Reset key	1

Installation

1

⚠ Do not overtighten screws   ↻ 0.6Nm

2

⚠ Do not overtighten screws   ↻ 0.6Nm

3

Functional Earth Wiring

4

5a

$+$ 470 Ω $-$ $-$ 470 Ω $+$

LED will illuminate when call point is activated

5b

$+$ 470 Ω $-$ $-$ 470 Ω $+$

LED will NOT illuminate when call point is activated

6

7

Note the alignment marks

8

Removal

A

B
2. PUSH
⇧ TOP ⇧
1. HOLD

C
✓

Testing

A

B

C
✓

Commissioning

The installation must conform to BS5839–1 (or applicable local codes).

LED Indicator

Illuminated red when call point is operated only in 470Ω mode.

Transparent Hinged Cover

To provide additional protection against accidental operation, a Transparent Hinged Cover, part no 44251-189, is available or 44251-175 for multiples of 10.